

Installation and Maintenance Manual Steam Operated Pumping Trap - Low Head Extra Capacity SOPT - LHX






Table of Contents

1.	Preface	1
2.	Important Safety Notes	1
3.	Product Information	3
4.	Product Working Principle	9
5.	Installation Guidelines	9
6.	Start-up and Commissioning	.11
7.	Maintenance Guidelines	.12
8.	Troubleshooting	.13
9.	Available Spares	15
10.	Warranty Period	17

PLEASE NOTE - Throughout this manual this cautionary symbol is used to describe a potential damage or injury that might occur if the safety considerations are overlooked. This symbol denotes CAUTION, WARNING or DANGER.







1. Preface:

This manual is intended for anyone using, commissioning, servicing, or disposing the below mentioned products safely and efficiently.

Steam Operated Pumping Trap - Low Head Extra Capacity





2. Important Safety Information:



Read this section carefully before installing/oparating/maintaining the product. The precautions listed in this manual are provided for personnel and equipment safety. Furthermore, Forbes Marshall accepts no responsibility for accidents or damage occurring as a result of failure to observe these precautions. Note that the product is designed to perform for non-contaminated fluids only. A contamination in the form of chemical, foreign particle etc. can lead to problem with product performance and life of the product.

If these products in compliance with the operating instructions are, properly installed, commissioned, maintained and installed by qualified personnel (refer Section 2.8) the safety operations of these products can be guaranteed. General instructions for proper use of tools and safety of equipments, pipeline and plant construction must also be complied with.

2.1 Intended use:

Check if the product is suitable for intended use/ application by referring to the installation and maintenance instructions, name plates and technical information sheets.

- The product is suitable for use as defined in the technical information sheet. In case
 the need arises to use the product on any other fluid please contact Forbes
 Marshall for assistance.
- ii) Check for the suitability in conformance to the limiting conditions specified in technical information sheet of the product.
- iii) The correct installation and direction of fluid has to be determined.
- iv) Forbes Marshall products are not intended to resist external stresses, hence necessary precautions to be take to minimize the same.

2.2 Accessibility and Lighting:

Safe accessability and working conditions are to be ensured prior to working on the product.



2.3 Hazardous liquids or gases in the pipeline:

Contemplate what may have been in the pipe or is in the pipe also for flammable Materials, substances hazardous to health, extremes of temperature.

2.4 Hazardous environment and media:

The product has to be protected from hazardous environment and check to encure that no Hazardous liquids or gases pass through the product.

2.5 Depressurizing of systems and normalizing of temperature:

Ensure isolation and safety venting of any pressure to the atmospheric pressure. Even if the Pressure gauge indicates zero, do not make an assumption that the system has been Depressurized. To avoid danger of burns allow temperature to normalize after isolation.

2.6 Tools and consumables:

Ensure you have appropriate tools and/ or consumables available before starting the work. Use of original Forbes Marshall replacement part is recommended.

2.7 Protective clothing:

Consider for the requirement of any protective clothing for you/ or other in the vicinity for Protection against hazards of temperature (high or low), chemicals, radiation, dangers to Eye and face, noise and falling objects.

2.8 Permits to work:

All work to carried out under supervision of a competent person. Training should be Imparted to operating personnel on correct usage of product as per installation and Maintenance instruction. "Permit to work" to be complied with (wherever applicable), in Case of absence of this system a responsible person should have complete information and Knowledge on what work is going on and where required, arrange to have an assistant with His primary goal and responsibility being safety. "Warning Notices" should be posted Wherever necessary.

2.9 Handling:

There is a risk of injury if heavy products are handled manually. Analyze the risk and use Appropriate handling method by taking into consideration the task, individual, the working Environment and the load.

2.10 Freezing:

Provision should be made to protect systems which are not self-draining. against frost Damage (in environment where they may be exposed to temperatures below freezing Point) to be made.

2.11 Product Disposal:

It is necessary to dispose this product only in accordance with local regulations at the authorized, qualified collecting point specified for equipment's and its parts—Please refer the part details mentioned in the material table of this manual. Please follow all waste disposal guidelines (Management & Handling) as published by local governing authorities in India & abroad



2.12 Returning products:

Customers and stockiest are reminded that, when returning products to Forbes Marshall they Must provide information on any hazards and the precautions to be taken due to Contamination residues or mechanical damage which may present a health, safety or Environmental risk.

This information must be provided in writing including Health and Safety data sheets Relating to any substances identified as hazardous or potentially hazardous.

3. Product information

Description

SOPT-LHX is a Steam Operated Pumping Trap - Low Head Extra Capacity with flanged connections. This innovative product is capable of working in trapping or pumping mode automatically, depending on the process conditions. The unit is operated by steam & is used to remove condensate from the process plant under all operating conditions including vacuum/stall.

Size & Connection

Model	Condensate Inlet	Condensate Outlet	Motive Steam inlet	Steam Exhaust	Drain
SOPT-LHX	50 NB (Class150)	40 NB (Class 150)	15 NB Screwed BSPT	25 NB Screwed BSPT	15 NB Screwed BSPT

Limiting Conditions

Sizes: 50 NB X 40 NB

Body design Conditions: PN16

Max. Operating Pressure: 13.8 barg @198° C

Max. Operating Temperature: 198° C @13.8 barg

Min. Operating Temperature: -10° C

Discharge per cycle: 6.7 Liters

Max. Cold hydraulic test pressure: 24 barg


Max. Back pressure: 5 barq

Minimum Installation Head: 200mm

Recommended Installation Head: 300mm




Dimentions:



Note: Approximate dry weight = 70 Kg

Sr.No	Description	Material
1	SOPT-LHX BASE	SG IRON ASTM A395 / EN-JS1025
2	SOPT-LHX COVER	SG IRON ASTM A395 / EN-JS1025
3	HEX SOCKET HEAD SCREW M12	ASTM A193 B7
4	15NB MOTIVE STEAM INLET (SCREWED)	SG IRON ASTM A395/ EN-JS1025
5	25NB STEAM EXHAUST (SCREWED)	SG IRON ASTM A395/ EN-JS1025
6	MAIN FLANGE GASKET	GRAPHITE
7	INTERNAL MECHANISM	STAINLESS STEEL
8	40NB FMDCV	STAINLESS STEEL







Item No.	Description	Material
1.	Base	ASTM A395/EN-JS1025
2.	Cover	ASTM A395/EN-JS1025
3.	Main Flange Gasket	Pure Graphite
4.	Trap seat Assembly	Stainless Steel
5.	Float Lever	Stainless Steel
6.	Float	Stainless Steel
7.	Crank Lever	Stainless Steel
8.	Anchor Link	Stainless Steel
9.	Actuator	Stainless Steel
10.	Support Bracket	Stainless Steel
11.	Steam Inlet Assembly	Stainless Steel
12.	Exhaust Seat Assembly	Stainless Steel
13.	Exhaust Valve Head Assembly	Stainless Steel
14.	Flap Seat Assembly	Stainless Steel
15.	Extension Spring	Stainless Steel
16.	15NB Strainer	Cast Steel
17.	Hex Socket head Cap Screw M12X45	ISO 4762
18.	40NB #150 FMDCV	Stainless Steel
19.	40NB GASKET	Graphite
20.	40NB #150 FLANGE	ASTM A105

Trapping Capacity Chart

Differential Pressure (bar g)	Capacity (Kg / hr)
1	7000
2	8500
3	9010
5	11800
7	11800



Pumping Capacity Chart (For Installation Head 1000mm)				
Motive Pressure (bar g)	Total Back Pressure (bar g)	Capacity (Kg/hr)		
2	0.5	2000		
3	0.5	1988		
3	1	1389		
3	2	869		
4	0.5	2258		
4	1	1759		
4	2	1181		
4	3	637		
5	0.5	2300		
5	1	1839		
5	2	1217		
5	3	905		
5	4	609		
6	0.5	2460		
6	1	1997		
6	2	1456		
6	3	1099		
6	4	912		
6	5	613		
7	0.5	2525		
7	1	2035		
7	2	1466		
7	3	1099		
7	4	851		
7	5	743		
8	0.5	2455		
8	1	2173		
8	2	1651		
8	3	1191		
8	4	901		
8	5	761		
9	0.5	2452		
9	1	2210		
9	2	1654		
9	3	1150		
9	4	901		
9	5	740		
10	0.5	2518		
10	1	2130		
10	2	1634		
10	3	1315		
10	4	927		
10	5	716		



11	0.5	2499
11	1	2187
11	2	1726
11	3	1385
11	4	925
11	5	735
12	0.5	2546
12	1	2229
12	2	1809
12	3	1486
12	4	1045
12	5	777
13	0.5	2538
13	1	2277
13	2	1816
13	3	1522
13	4	1010
13	5	751
13.8	0.5	2500
13.8	1	2231
13.8	2	1832
13.8	3	1511
13.8	4	1173
13.8	5	823

Note

Pumping capacities shown in above chart are for condensate temperature of 90° C. For higher back pressures & different filling heads contact factory.

Note:

1. Total lift or back BP (static head plus pressure head in the return system) must be below the motive fluid inlet pressure to allow pump capacity to be achieved.

 $BP = (H \times 0.0981) + P + Pf$

Where - BP - Back pressure in bar g

H - Height in meters

P-Pressure in return line in bar g

Pf - Piping frictional pressure drop in bar g

(Pf can be ignored if the downstream pipework is less than 100 meters to a non flooded condensate return and has been sized to take into account the effect of flash steam at the heat exchanger's full load operating conditions.)



4. Product working principlele

The SOPT-LHX automatic pump trap operates on positive displacement principle. Condensate enters the body through the inlet swing check valve causing the float to rise. The float is connected to the trap mechanism. If the upstream system pressure PS is sufficient to overcome the back pressure. The buildup of condensate will be discharged by opening two orifice trap mechanism.

- * In this way, the float will automatically modulate according to the rate of condensate entering the SOPT-LHX, controlling the rate of opening and closure of the trap.
- * With some temperature controlled equipment, it is possible that the system pressure PS may get lower than the back pressure.
- * If this occurs a standard trap will stall, allowing the condensate to flood the equipment being drained.
- * However, with the SOPT-LHX, the condensate simply fills the main chamber lifting the float until the changeover linkage is engaged, opening the motive inlet and closing the exhaust valve.
- * The snap action mechanism ensures a rapid change from the trapping mode to the active Pumping mode. With the motive inlet valve open, the pressure in the SOPT-LHX increases above the total back pressure and the condensate is forced out through the trap seat into the plant's return system.
- * As the condensate level falls within the main chamber, the float makes the mechanism snap again ,causing the motive inlet to close and the exhaust valve to open.
- * As the pressure inside the SOPT-LHX equalizes with the condensate inlet pressure through the open exhaust valve, condensate re-enters via the inlet swing check valve. At the same time the outlet ball check valve ensure no condensate can drain back into the main chamber and the trapping or pumping cycle begins again.

5. Installation Guidelines

Before any installation or maintenance procedure, always ensure that all steam or Condensate lines are isolated.

Ensure any residual internal pressure in the product or connecting lines is carefully relieved. Also ensure any hot parts have cooled to prevent risk of injury from burns. Always wear Appropriate safety clothing before carrying out any installation or maintenance work.

A lifting point is on the top of the body. On no account should this be used lift anything More than the total weight of the product (70 kgs). Always use suitable lifting gear and ensure the product is safety secured.


Note: If pumping a potentially explosive media, the motive supply media must be an inert gas with no oxygen present.



5.1 Inlet piping

To prevent condensate backing up into the equipment being drained, it is recommended that the inlet pipework is sufficiently sized to accumulate condensate during the pump's discharge cycle. Generally a length and diameter of pipe to accommodate 10 litres of condensate will be sufficient. It is essential that a Forbes Marshall Y-type strainer with a maximum 0.8 mm perforation screen size is fitted at the condensate inlet of the

SOPT-LHX.



1	50 NB Isolation Valve		
2	50 NB Forbes Marshall FMSTR31 Strainer 0.8 Mesh		
3	40 NB Forbes Marshall Disk Check valve (FMDCV)		
4	15 NB Forbes Marshall Screwed Strainer (FMSTR51) Dutch Weave type		
5	15 NB Forbes Marshall Piston valve		
6	Pressure Gauge with syphon		
7	15 NB Forbes Marshall Thermodynamic trap		
8	15 NB Forbes Marshall Soft seated Disk check valve (If supplied)		
9	15 NB Forbes Marshall Air vent (If supplied)		
10	25 NB Forbes Marshall Piston Valve		
11	15 NB Vent Isolation Valve		



5.2 Guidelines for Motive steam line connection:

At a minimum, the inlet piping should be at least 25 mm (1") pipe from the steam header dropping to the SOPT-LHX. Only when the steam (motive) inlet pipework is close to 0.5 m to the pump should the motive line piping be reduced to 1/2" / 15NB and fed to the SOPT-LHX.

5.3 Airvent

(If supplied) 15NB Air vent with Air vent isolation valve and soft seated 15NB FMDCV must be fitted on the balancing line at elevation higher than Steam inlet as shown in installation diagram

5.4 Recommended installation head

Installation head is least 0.2 m from the base of the SOPT-LHX unit.

Note: During cold start-up conditions, it is possible for hydraulic pulsing of the inlet check valve to occur. It is advisable in this case to install a throttling isolation valve to reduce the filling pressure.

5.5 Connections (refer to installation diagram)

The SOPT-LHX has four connection ports. The DN40 (1 1/2") port should be connected to the outlet of the equipment being drained, 40NB FM Disk check valve (It comes with the product) must be installed after SOPT-LHX as shown in installation diagram. And the DN50 (2") port should be connected to condensate inlet line. Flow should be from 50NB port to 40NB port. The DN15 (1/2") port should be connected to a trapped motive steam supply. (*It is important to ensure this line is drained of condensate at all times using a Forbes Marshall Thermodynamic steam trap and steam is fed to SOPT-LHX though 100 mesh strainer or dutch weave strainer). The screwed DN25 (1") port should be balanced back as close as possible to the condensate outlet of the equipment. This balance line must always be connected to the top of the condensate inlet pipe, as shown in Fig. It is recommended that this balancing line should be hard line for typical vacuum application.

5.6 Outlet piping

It is important for the outlet piping to be correctly sized to prevent excessive back pressure on the SOPT-LHX. This pipework should be sized to take into account the effects of flash steam at the heat exchangers full load operating condition.

6. Startup and Commissioning

- * After ensuring the inlet and outlet pipe connections and motive / exhaust connections are coupled in accordance with Installation diagram, slowly open the motive steam inlet line to supply pressure to the SOPT-LHX. Ensure the exhaust /balance line is open and not restricted in any way.
- * Slowly open the isolation valves in the condensate inlet and discharge lines, allowing condensate to fill the body of the SOPT-LHX.
- * The SOPT-LHX is now ready to operate.



- * When the process plant is operational, the SOPT-LHX will discharge condensate under pressure conditions as per specifications into the return line.
- * If any irregularities are observed, recheck the installation according to the recommendations. If the unit fails to operate, then consult the fault finding section.

7. Maintenance Guidelines

7.1 Mechanisms inspection and repair

7.2 Removal and fitting of base assembly

Please ensure the safety recommendations are observed before commencing with any maintenance of this product.

Tools required

10A/F Allen Key, Flat blade screw driver, Torque wrench, 19 A/F spanner, 19 Hex socket.

7.3 To remove the Base Asslv

- **7.3.1** After removing flange bolt, remove base assly carefully, so that there is no damage to SOPT-LHX internal mechanism.
- **7.3.2** Visually inspect the mechanism for obvious damage. Check that it is free of dirt and scale and operates freely when the floats are moved up and down.
- **7.3.3** Inspect the spring assembly for damage. Make sure the valves slide freely and the spring loaded exhaust valve moves on its guide.
- **7.3.4** Inspect the floats to ensure they are undamaged. Check all the pivot point to ensure they are moving freely.
- 7.3.5 Ensure the inlet swing check valve is free to move and the sealing faces of both the seat and the flap are clean and undamaged. (If the seat is badly scored or damaged a new swing check valve assembly may be required).
- 7.3.6 Check the two outlet orifices are free from dirt and debris. Ensure they open and close smoothly.

7.4 If a Base is to be fitted

- 7.4.1 Ensure the gasket face in the body is clean and free from debris. Carefully slide the new cover assembly into the existing body, whilst ensuring the new gasket is carefully aligned with the gasket faces and no parts of it are trapped or pinched outside the sealing areas.
- **7.4.2** Refit the Base bolts ensuring they are sequentially tightened in opposing pairs, gradually increasing torque to 90-100 N m

Hex. head / Hex. socket head cap screw	Tools	Torque
M12 x 40	Allen Key 10 A/F	
M12 x 35	Hex Head 19 Spanner	90-100 N-m
M12 x 70	Hex Head 19 Socket	

7.4.3 Carefully reconnected the motive steam supply and the exhaust lines to the connections marked (IN) and (OUT), then follow the start-up procedure as mentioned in section 6 commissioning to bring the SOPT-LHX back into operation.



8. Trouble Shooting

Installation and troubleshooting should only be performed by qualified personnel. Before any maintenance is attempted, ensure any residual internal pressure in the product or connecting lines is carefully relieved. Also ensure any hot parts have cooled to prevent risk of injury from burns. Always wear appropriate safety clothing before carrying out any installation and maintenance work.

A lifting point is on the top of the body. On no account should this be used to lift anything more than the total weight of the product (70 kgs). Always use suitable lifting gear and ensure the product is safely secured. When dismantling this product, care should be taken prevent injury from the snap action mechanism. Always handle with care.

The SOPT-LHX has been throughly tested before it leaves the factory. This includes a Comprehensive functional test. If the unit has failed to operate it is likely that an installation Problem could exist. Please check the following before commencing with the trouble-Shooting chart.

Trouble areas to check first

- Are all isolating valves open?
- * Is the condensate inlet strainer clean and free from debris?
- * Does the installation head available exceed 0.2 m from the base of the SOPT-LHX?
- Is the available motive pressure is less than the total back pressure? (not exceeding 14 barg)
- * Is the exhaust balance line (OUT) connected to the outlet of the equipment being drained and is it free from obstruction (refer to installation diagram)?
- * Is the direction of flow though the unit correct from inlet to outlet?



Trouble-shooting guide

SYMPTOM SOPT-LHX fails to operate on start up

CAUSE 1 CHECK and CURE	No motive pressure. Motive supply pressure exceeds total back pressure.
CAUSE 2 CHECK and CURE	Inlet isolation valve maybe closed. Inlet pipe is free from obstructions and the isolation valve is open
CAUSE 3 CHECK and CURE	Motive inlet and exhaust lines incorrectly connected. Motive = IN, Exhaust = OUT.
CAUSE 4 CHECK and CURE	The rate of condensate produced by the process maybe very low, causing The SOPT-LHX to cycle slowly. The process being drained is operating correctly.
SYMPTOM CAUSE 1 CHECK and CURE	Equipment Flooded and SOPT-LHX stopped Cycling Blocked exhaust line Balance line is free from obstruction and is not waterlogged. Refer to Installation diagram.
CAUSE 2 CHECK and CURE	Blocked condensate inlet line. Inspect and clean the strainer mesh, check for blockages.
CAUSE 3 CHECK and CURE	Blocked condensate outlet line. Inspect line for blockages.
CAUSE 4 CHECK and CURE	Damaged mechanism. Mechanism operates as shown in working principle section Replace malfunctioning part.
CAUSE 5 CHECK and CURE	No motive steam available. Steam supply to SOPT-LHX is available and at the correct pressure. Motive Pressure must exceed total backpressure.
CAUSE 6 CHECK and CURE	Leaking motive inlet valve. If SOPT-LHX body is not (observe safety note), this indicates the SOPT-LHX Mechanism is stuck on the discharge cycle. Check mechanism for Excessive friction. Check motive inlet valve and spring For correct operation - replace malfunctioning part.
CAUSE 7 CHECK and CURE Broken spring. If SOPT-LHX body is cold, this indicates the SOPT-LHX mechanis on The filling cycle. Check pump mechanism spring - replace malf Part.	
SYMPTOM	Equipment Flooded but SOPT-LHX appears to cycle normally
CAUSE 1 CHECK and CURE	SOPT-LHX is undersized for the application. Check system parameters agree with the custom sizing sheet / graph.
SYMPTOM CAUSE 1 CHECK and CURE	Chattering or banging in SOPT-LHX discharge line Live steam entering discharge line. Ensure steam traps draining the motive supply line are discharging to a non-flooded condensate return. Condensate return is adequately sized.
SYMPTOM CAUSE 1 CHECK and CURE	Chattering or banging of SOPT-LHX inlet check valve flap Hydraulic pulsing of the inlet check valve Reduce installation head to SOPT-LHX install throttling valve on SOPT-LHX Condensate inlet.



9.1. Available Spares

SR.NO	DESCRIPTION	PART CODE NO.	KIT VIEW
1	mechanism assembly kit	SPARE-050SOPT-LHX-MKIT	
2	Inlet valve seat assembly kit	SPARE-050SOPT-LHX-IVKIT	TORQUE: 75 - 85 Nm TOOL REQUIRED: 22 A/F SPANNER
3	Exhaust valve head assembly kit	SPARE-050SOPT-LHX-EVKIT	TORQUE: 75 - 85 Nm TOOL REQUIRED: 22 A/F SPANNER
4	*Gasket kit	SPARE-050SOPT-LHX-GKIT	



SR.NO	DESCRIPTION	PART CODE NO.	KIT VIEW
5	Support Bracket assembly Kit	SPARE-050SOPT-LHX-SBKIT	TORQUE: 18 - 22 Nm TOOL REQUIRED: 6 mm ALLEN KEY
6	Trap seat assembly kit	SPARE-050SOPT-LHX-TSKIT	TORQUE: 18 - 22 Nm TOOL REQUIRED: 6 mm ALLEN KEY
7	Inlet check valve assembly kit	SPARE-050SOPT-LHX-ICVKI	TORQUE: 37 - 43 Nm TOOL REQUIRED: 8 mm ALLEN KEY
8	Float assembly kit	SPARE-050SOPT-LHX-FKIT	TORQUE: 7 - 9 Nm TOOL REQUIRED: 5 mm ALLEN KEY

^{*} Order Gasket kit with all other Spare Kits.



10. Warranty Period

As per ordering information and agreements in the contract.

Disclaimer:

This information is strictly proprietary and legally privileged. All contents herein shall be the property of Forbes Marshall Pvt Lid and having under the intellectual property rights. No part of this information or data may be distributed or disclosed in any form to any third party.

Any dissemination, use, review, distribution, printing or copying is strictly prohibited, if you are not the intended recipient or user of this information.



www.forbesmarshall.com

Forbes Marshall Arca Godel International Krohne Marshall Forbes Vyncke Forbes Marshall Steam Systems

A: Forbes Marshall Pvt. Ltd.

Opp. 106th Milestone, CTS 2220, Mumbai-Pune Road, Kasarwadi, Pune MH 411034 INDIA P: +91(0)20-68138555 F: +91(0)20-68138402

E: ccmidc@forbesmarshall.com

Forbes Marshall International Pie. Ltd.

16A, TuasAvenue 1, #05-21, JTC Space @Tuas Singapore - 639533 P. +65 6219 3890

CIN No: U28996PN1985PTC037806

© All rights reserved. Any reproduction or distribution in part or as a whole without written pe†mission of Forbes Marshall Pvt Ltd, its associate companies or its subsidiaries (FFM Group') is prohibited. Infofmation, designs or specifications in this document are subject to change without notice. Responsibility for suitability, selection, installation, use, operation or maintenance of the product(s) rests solely with the purchaser and/or user. The contents of this document are presented for informational purposes only. PM Group disclaims liabilities or losses that may be incurred as a consequence of the use ofthis/info/mation.